




RT89
(spring)



Cat.No.	A	L	L1	B	B1
03.1111	3	70	48	55	38
03.1112	3	80	60	65	45
03.1113	3	60	36	76	56





RT90A Cat.No. 03.1114



Spring hinge RT90A

RT90B Cat.No. 03.1115



Hinge bearing RT90B
(without spring)